



SuperSonic Matrix Mid SC-999 Headphone Jack Replacement

This guide will teach you how to replace the 3.5mm headphone jack for the device.

Written By: Harris Dagha



INTRODUCTION

In this guide you will open up the back of the device and locate the 3.5mm headphone jack on the mother board. Once it is found you must remove it with a soldering iron and replace it.


Because this task requires the use of a soldering iron, prior experience with soldering/desoldering will be beneficial.



TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Safety Glasses](#) (1)
 - [Soldering Station](#) (1)
-

Step 1 — Back Cover



- Wedge the plastic opening tool between the back cover of the device and the front panel.
- You will hear a *snapping* sound as the cover is separated from the body of the device.

Step 2




- Slide the opening tool along the seam between the front panel and the back cover to un-clip the remaining connections around the device.
- Again, you will hear a *snapping* sound as the cover is separated from the body of the device.

Step 3



- Lift the back cover from the body of the device to expose the internal components.

Step 4 — Headphone Jack



- Locate the headphone jack on the device.

Step 5



- Desolder the 5 soldered connections (marked in red) that connect the headphone jack to the device.
- ✦ If you're unfamiliar with soldering or desoldering check out [this guide](#).
- ⚠ Be sure to wear protective eye wear. The soldering iron will become extremely hot, so be mindful in your handling.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 11:18:05 PM.